

Before use, please read thoroughly the instructions for use and the general safety instructions!

Instruction for use and general safety instructions for metal construction

The metal construction serves as the basis of the garden seating SWINGEAT and is supposed to be fixed with panels from e.g. wood, plastic or metal. Metal construction cannot be used without panels installed. When making the panels, make sure there is no overlapping between the individual parts.

We recommend the following dimensions for the panels:

- backrest width 143 cm, height is optional;
- seatrest length 150 cm, depth is optional;
- table length 150 cm, width is optional;
- platform with dimensions 138 x 135 cm.

If you have any questions, please do not hesitate to contact us.

Materials used and maintenance:

The metal construction is made in black matt finish for outdoor use. Use damp cloth to clean the construction. The shade is made of synthetic impregnated fabric with UV stabilizers. It is not recommended to machine wash the shade, only wipe with damp cloth. The mechanism of movement is made of non-rusting material and therefore is maintenance free. If when swinging you hear a noise from the parts where the movement mechanism is located or the movement is no longer as smooth as before, please clean the parts of seating where the mechanism is located. When cleaning, the garden seating must be locked for movement.

Preparation for winter:

Before the temperatures drop below zero, choose a nice dry day to prepare the garden furniture for winter. If you have cloth roof, please remove it, it is possible that it would not resist the weight of snow. Dry the cloth roof and keep it nicely folded in a dry place. You can cover the whole product with a waterproof sheet and fix it carefully.

If you can keep the garden seating inside in a dry place, do so. This way you can prolong the product's life. The garden furniture can be dismantled.

General safety instructions:

The garden swinging seating is intended for slight relaxing swinging; the recommended swing to both sides is approx. 20 cm. The product is equipped with a stop limiting its movement; however, we strongly discourage the movement where you hit the stop because the objects placed on the table may fall down. Please do not put your hands, feet or any other parts of your body close to the movement mechanism. The product is neither a toy nor playground equipment. Children are not allowed to use the product unsupervised, therefore, their safety is their supervisor's responsibility.

The seating must remain locked at all times when not in use. When getting in and out the seating must be secured with a pawl. Before swinging, please make sure that no one/nothing is close to the seating and under the seats, especially below, or close to the movement mechanism or any other moving part of the seating. The load bearing capacity of the construction is upto 800 kg. The load bearing capacity of the benches depends on used material. Distribute the load evenly and do not put too much load on one side only.

When swinging, especially when hitting the pawl, objects on the table may topple, drinks may be spilt, etc. So, please, be very careful, mainly when swinging with hot food and drink, and sharp objects.

Do not use this product when damaged, broken or incomplete, and contact us on the phone number stated in the header. Any handling that is inconsistent with the instructions for use is absolutely forbidden, because it can result in serious injury to the person or irreparable damage to the product and only you will be held responsible.

The garden seating is intended for use on a horizontal surface.

The warranty is 2 years on purchase of the product. The warranty does not include damage caused to the product as a result of inconsistency with the instructions of use, prohibited handling or malicious mechanical damage.

